OWNER'S MANUAL | SKU CCC-185

Crotic Cane Chair

Black wood, an open cane seat and a broad wooden backrest. Simple care helps preserve the weave, finish and frame.



Black finish shown

Product at a glance

OVERALL SIZE - EACH 18.5" W x 21.2" D x 31" H 47 x 53.8 x 78.7 cm	**SEAT HEIGHT** 17.9" (45.5 cm) Single chair or pair available
CONSTRUCTION Solid Kikar main frame Solid Kikar seat surround	**SEAT** Natural cane webbing Open weave; no upholstery
BACKREST & LEGS Broad wooden panel Crossed wooden leg frame	**ASSEMBLY** Delivered fully assembled No customer assembly required

Before first use

- Remove packaging carefully. Keep blades away from the cane and finished wood.
- Check your order quantity: one chair or a pair of two. Inspect the frame, weave and joints before use.
- Place on a dry, level indoor floor. Check that the chair sits evenly and feels stable.

Everyday use

- Each chair seats one person. Sit evenly; do not stand, kneel or jump on the cane.
- Lift using the wooden frame. Never drag or lift by the cane or backrest.

CARE & MAINTENANCE

Care for wood and woven cane

The cane seat is exposed and unupholstered. Gentle cleaning and even sitting pressure help protect the weave and its attachment to the wooden surround.

Cane seat	Remove dust with a soft brush, taking care around the edges. Do not pull strands or use sharp tools to clear the openings.
Wood frame	Dust the Kikar frame and wooden backrest with a soft cotton cloth. For light marks, use a well-wrung damp cloth, then dry promptly.
Spills	Blot spills on the cane immediately with a clean, absorbent cloth. Do not soak or scrub the weave. Let it dry naturally before use.
Black finish	Avoid abrasive pads, bleach, solvents, and unapproved furniture oils or polishes. Do not steam-clean the cane or wood.
Seat pressure	Sit with weight spread across the seat. Do not kneel, stand or place heavy objects with small contact points on the cane.
Moving & checks	Lift from the wooden frame. Check occasionally for loose joints, broken strands or detachment. Stop use and contact ROCO if any appear.

PLACEMENT & SUPPORT

Use it well.
Keep it supported.

The Crotic Cane Chair is intended for indoor use on a dry, level surface. When using it at a table, check seat height and table clearance.

Important precautions

- Keep away from rain, damp walls, heaters, open flames, prolonged direct sunlight and direct air-conditioning airflow.
- Do not rock or lean back on two legs. Keep children from climbing on the backrest or playing beneath the frame.
- Do not force, fold, drill or dismantle the frame. A crossed-leg appearance is not an instruction to fold the chair.
- If the chair wobbles, joints move, cane breaks or structural noise persists, stop using it and contact ROCO.

Warranty guidance

The ROCO Confidence Warranty and written terms for your order apply. Eligible manufacturing defects in the solid Kikar load-bearing frame and structural joints receive 24-month coverage. The indoor black finish receives 6-month coverage for verified premature peeling or adhesion failure caused by manufacture. Natural cane and its installation follow the specific terms confirmed for your order.

Coverage normally begins at delivery. ROCO assesses the issue and normally repairs or replaces the affected component first. Normal wear, natural variation, scratches, fading, moisture damage, misuse and unauthorised alterations are excluded. Obtain ROCO instructions before arranging repairs or a return.

ROCO CUSTOMER CARE

Need assistance?

Contact ROCO if something does not look, feel or perform as expected. Clear information helps us assess the concern.

When to contact us

- Report visible transit damage, a wrong item or missing chair within 48 hours of delivery. For a pair, check both chairs.
- Report levelling, alignment or fitting concerns within 7 days. These inspection windows do not replace the applicable warranty period.
- Stop use if the chair is unstable or the cane is damaged. Report hidden manufacturing concerns during the warranty period for your order.

What to share

Share your order or invoice number, product name, delivery date and a description of the issue. Add clear photographs of the whole chair and affected area, plus a short video for movement or noise. For a pair, identify which chair is affected.

WHATSAPP	+92 317 6965610
EMAIL	info@roco.pk
AFTER-SALES	roco.pk/after-sales-request/
WARRANTY	roco.pk/warranty-policy/

Version 1.0 | October 2026 | Keep with your order record.
Custom materials, dimensions and finishes follow your written order.