

OWNER'S MANUAL

Script Trestle Writing Desk

Compact three-drawer workspace with a Kikar-led wooden base. Regular care helps preserve the worktop, drawer alignment and stable stance.



Product at a glance

OVERALL SIZE 50 in W x 23.75 in D x 30 in H 127 x 60.3 x 76.2 cm	CONSTRUCTION Kikar-led mixed construction
STORAGE 3 slim drawers	ASSEMBLY Delivered fully assembled
FINISHES Brown / Walnut	PROFILE 50 in trestle writing desk

Before first use

- Remove packaging carefully. Keep blades and sharp tools away from the worktop, veneer edges, drawer fronts and wooden legs.
- Place the desk on a dry, level indoor surface with enough clearance for all three drawers. Confirm that the desk stands evenly before loading it.
- Inspect the finish, drawer alignment, knobs and visible condition. Report visible delivery concerns within 48 hours and setup, alignment or stability concerns within 7 days where applicable.

Everyday use

- Use the desk for writing, study and home-office work. Distribute items across the worktop and do not sit or stand on the desk.
- Open drawers using the knobs and close them gently. Use desk mats or coasters beneath frequently moved items. Before moving, empty the drawers and lift with two people; never drag the desk by its legs.

CARE & MAINTENANCE

Care for the worktop, drawers and wooden base

The Script Trestle Writing Desk combines solid Kikar structural elements, furniture-grade plywood, natural wood veneer and selected engineered components. Simple desk-specific care helps preserve the finish, drawer movement and stable stance.

Worktop	Keep the surface free of grit before moving laptops, books or accessories. Use a desk mat, coaster or felt pad beneath frequently used objects.
Kikar & veneer	Dust with a soft, dry microfiber cloth. For light marks, use a barely damp cloth and dry immediately. Wipe with the grain where practical.
Spills	Blot spills quickly, then dry the area. Do not allow standing moisture around veneer edges, drawer joints or the base.
Drawers	Open from the knobs and avoid slamming or overfilling. Keep slide areas free of debris and never force a drawer that binds or feels uneven.
Cleaning	Avoid bleach, acetone, thinner, abrasive cleaners, strong chemical polish, excessive water and steam cleaning.
Legs & stability	Check the wooden legs, joints and fittings periodically. Keep the desk level and stable; contact ROCO if unusual movement or looseness develops.

PLACEMENT & SUPPORT

Keep the workspace steady and clear.

The Script Trestle Writing Desk is intended for indoor study, bedroom and home-office use in a dry, well-ventilated setting.

Important precautions

- Keep the desk away from damp walls, water sources, heaters, open flames and prolonged direct sunlight.
- Place it on a level floor with full drawer clearance. Keep power and charging cables routed so they cannot snag on drawers or the wooden base.
- Do not overload the worktop or drawers, sit or stand on the desk, or use an open drawer as a step or support.
- Do not drill, dismantle, modify the base or arrange third-party structural repair without written guidance from ROCO.
- If the desk becomes unstable, a drawer binds, a fitting loosens, or unusual movement, cracking or persistent noise develops, stop using the affected area and contact ROCO for assessment.

Warranty guidance

Your Script Trestle Writing Desk is supported by the ROCO Confidence Warranty and any product-specific terms confirmed on the product page, quotation, invoice or written order confirmation. For this mixed-construction product, eligible structural defects in the Kikar / plywood assembly and standard hardware defects are normally covered for 12 months; qualifying indoor veneer or ROCO-applied finish adhesion defects are normally covered for 6 months. Product-specific written terms take priority.

ROCO normally begins with assessment, adjustment, repair or replacement of the affected component. Normal wear, scratches, overloading, moisture damage, harsh cleaning, accidental damage, misuse, unsuitable placement and unauthorised alterations or repairs are not normally covered as manufacturing defects. Report visible delivery concerns within 48 hours and setup, alignment, stability or missing-fitting concerns within 7 days where applicable.

ROCO CUSTOMER CARE

Need assistance?

Contact us early if something does not look, feel or perform as expected. Clear information helps us assess the concern more quickly.

When to contact us

- Report visible transit damage, a wrong item or a major visible delivery concern within 48 hours of delivery.
- Report initial drawer alignment, loose hardware, instability, missing fittings or setup concerns within 7 days where applicable.
- Report a hidden manufacturing, material or workmanship concern during the warranty period applicable to the affected component and your order.

What to share

Please share your order or invoice number, the product name, clear photographs of the complete desk and the affected area, and a short video if the concern involves drawer movement, stability, alignment or noise.

WHATSAPP	+92 317 6965610
EMAIL	info@roco.pk
AFTER-SALES	roco.pk/after-sales-request/
WARRANTY	roco.pk/warranty-policy/

Version 1.1 | October 2026 | Keep this manual with your order record.