OWNER'S MANUAL

Larsen Cane Sofa

Armchair · Two-Seater · Three-Seater

A solid Sheesham frame with woven cane sides, separate cushions and two cylindrical bolsters per piece.



Three-seater shown

Product at a glance

ARMCHAIR OVERALL 43 × 38 × 33 in 109.2 × 96.5 × 83.8 cm	**TWO-SEATER OVERALL** 65 × 38 × 33 in 165.1 × 96.5 × 83.8 cm
THREE-SEATER OVERALL 87 × 38 × 33 in 221.0 × 96.5 × 83.8 cm	**FRAME & FINISH** Solid Sheesham principal frame Natural cane sides, walnut-brown finish
STANDARD UPHOLSTERY Textured woven polyester Selected fabric per written order	**CUSHIONING & SUPPORT** Foam with polyester fibre padding Upholstery webbing under the seats

Overall dimensions are width × depth × height. Custom sizes follow your written order.

Before first use

- Check the frame, cane, cushions and bolsters against your order on arrival.
- Check any supplied fittings and follow the setup guidance on page 3.
- Make sure the piece sits level and stable before use.

CARE & MAINTENANCE

Care for wood, cane and fabric

Use gentle cleaning methods for the exposed frame and woven sides. Follow the care guidance for the upholstery selected for your order.

Woven cane	Lift dust from the side panels with a soft brush. Keep sharp objects and concentrated pressure away from the weave. Avoid soaking or steam cleaning.
Wood finish	Dust with a soft, dry cloth. Keep wet items and cleaning sprays off the arms and rails. Ask ROCO before applying oils, waxes or polish.
Upholstery	Lift loose cushions and use a soft upholstery attachment on low suction along seams and the seat base. Follow the cleaning instructions for your fabric.
Spills & cleaners	Absorb spills with a clean, dry cloth. Avoid rubbing, soaking or using untested cleaners. Check with ROCO before removing or washing covers.
Cushions & bolsters	Straighten the seat cushions, gently reshape the back cushions and reposition the bolsters as needed. Keep weight off the arms and cane panels.
Placement & moving	Avoid prolonged sunlight, damp walls and nearby heaters. Lift beneath the structural wooden base with enough help. Avoid dragging or lifting by the arms or cane.

PLACEMENT & SUPPORT

Set up your Larsen

Use a dry, level indoor floor. Check doorways, stairs and lifts against the size ordered, and allow room to move safely around the piece.

Setup and safe use

- Confirm the delivery format and any setup service in your written order. Arrange enough help to lift and position the piece.
- Follow ROCO's instructions for any legs or supports supplied separately. If a fitting or instruction is missing, contact ROCO before setup.
- Place the seat and back cushions and position the two bolsters. Check that all legs and any centre supports are secure and the piece sits level.
- Keep weight off the arms and cane panels. If the frame rocks, a joint loosens or a support shifts, stop use and contact ROCO.

Warranty guidance

Standard coverage for eligible defects is 24 months for the qualifying wooden frame and structural joinery, 12 months for foam, seat webbing and upholstery workmanship, and 6 months for ROCO-supplied fabric and indoor finish. Any specific coverage, including for cane, follows your written order.

Coverage normally starts on delivery. Ordinary wear, gradual foam softening, natural material variation and damage from moisture, misuse or unsuitable cleaning are generally excluded. ROCO assesses the affected component and considers repair before replacement.

Full coverage, exclusions and claims guidance at roco.pk/warranty-policy/

ROCO CUSTOMER CARE

Need assistance?

Contact ROCO if the frame, cane panels, upholstery or fittings need attention. Your order details and clear photographs help us assess the issue.

When to contact us

- Report visible transit damage or wrong or missing items within 48 hours of delivery.
- Report installation, levelling, alignment or missing fittings within 7 days.
- Report hidden manufacturing defects during the applicable warranty period. The delivery and setup reporting windows do not shorten that period.

What to share

Send your order or invoice number, seating size, fabric and finish, delivery location and a brief description. Include photos of the whole piece and affected area, plus video for movement or noise. Contact ROCO before arranging repairs or returns.

WHATSAPP	+92 317 6965610
EMAIL	info@roco.pk
AFTER-SALES	roco.pk/after-sales-request/
WARRANTY	roco.pk/warranty-policy/

Version 1.0 | 6 November 2026 | Keep this manual with your order record.