

OWNER'S MANUAL

AirCush Deep-Seat Armchair

A deep, generously cushioned armchair for relaxed everyday seating. Simple care will help preserve its comfort, upholstery and structure.

Product at a glance

OVERALL SIZE 96 cm W x 115 cm D x 72 cm H 37.8 in W x 45.2 in D x 28.3 in H	STRUCTURE Kikar hardwood frame with furniture-grade plywood sides and back
SEAT CUSHIONING 4 in Molty high-density foam with polyester fibre wrap	BACK CUSHIONING Molty foam with softer fibre layering
UPHOLSTERY ROCO-approved fabric	ASSEMBLY Delivered fully assembled

Before first use

- Remove packaging carefully. Keep blades and sharp tools away from the upholstery, seams and cushion edges.
- Place the chair on a dry, level indoor surface. Allow the seat and back cushioning to settle naturally after transit.

Everyday use

- Use as a single-person armchair. Do not stand, jump or place concentrated weight on the arms or back.
- Lift from the lower frame when moving the chair; do not drag it or pull it by the upholstered arms.

CARE & MAINTENANCE

Care for the seat you settle into

Your selected upholstery may have specific care requirements. If a treatment is uncertain, contact ROCO before applying it.

Upholstery	Vacuum gently with a clean upholstery attachment, including seat seams, cushion edges and the inside faces of the arms. Limit prolonged direct sunlight to help reduce uneven fading.
Spills	Blot promptly with a clean, colourfast absorbent cloth. Work from the outside inward. Do not rub, scrub or saturate the fabric.
Cleaning	Avoid bleach, acetone, thinner, abrasive cleaners, excessive water and unapproved steam cleaning. Contact ROCO if a stain or treatment is uncertain.
Cushioning	Allow the seat and back to recover naturally after extended use. Gradual softening and light body impressions can develop with regular seating and are not unusual.
Moving	Lift from beneath the lower frame, preferably with two people. Do not drag the chair across the floor or use the upholstered arms as lifting points.

PLACEMENT & SUPPORT

Give a deep seat room to settle.

AirCush is intended for dry, well-ventilated indoor residential spaces. Check access carefully before moving its 115 cm-deep frame between rooms.

Important precautions

- Keep the chair away from damp walls, water sources, heaters, open flames and prolonged direct sunlight.
- Do not climb, stand or sit on the arms or back. Keep pets, sharp objects and rough surfaces away from the upholstery.
- Do not drill, dismantle, reupholster or arrange structural repair without written guidance from ROCO.
- If the chair becomes unstable or develops unusual movement or persistent structural noise, stop using it and contact ROCO.

Warranty guidance

Your chair is supported by the ROCO Confidence Warranty and the product-specific terms confirmed with your order. Coverage is component-specific and may apply to eligible defects in the Kikar frame, plywood structure, seat webbing, Molty foam, upholstery workmanship and ROCO-supplied fabric. ROCO normally begins with assessment, adjustment, repair or replacement of the affected component.

Normal wear, gradual foam softening, body impressions, fabric stretching, fading, stains, moisture damage, misuse and unauthorised repair or modification are not manufacturing defects. Report visible delivery concerns within 48 hours and contact ROCO before arranging any repair or return.

ROCO CUSTOMER CARE

Need assistance?

Contact us early if something does not look, feel or perform as expected. Clear information helps us assess the concern more quickly.

When to contact us

- Report visible transit damage, a wrong item or a major visible delivery concern within 48 hours of delivery.
- Stop using the chair and contact ROCO if the frame or base becomes unstable, or if you notice unusual movement or persistent structural noise.
- Report a hidden manufacturing, material or workmanship concern during the warranty period applicable to your order.

What to share

Please share your order or invoice number, the product name, clear photographs of the complete chair and the affected area, and a short video if the concern involves movement or noise.

WHATSAPP	+92 317 6965610
EMAIL	info@roco.pk
AFTER-SALES	roco.pk/after-sales-request/
WARRANTY	roco.pk/warranty-policy/

Version 1.0 | September 2026 | Keep this manual with your order record.