

OWNER'S MANUAL

Meridian Outdoor Sofa Set

A Teak and woven-rope outdoor collection designed for relaxed seating, removable cushion comfort and coordinated outdoor spaces. This manual covers both Meridian set configurations and the care needed to preserve their appearance and function.

STANDARD CONFIGURATION 1 x 2-Seater + 2 x Chairs 1 x Coffee Table	LARGER CONFIGURATION 1 x 3-Seater + 1 x 2-Seater 1 x Chair + 1 x Coffee Table
3-SEATER 72 in W x 31 in D x 26 in H 183 x 79 x 66 cm	2-SEATER 59 in W x 31 in D x 26 in H 150 x 79 x 66 cm
LOUNGE CHAIR 31 in W x 31 in D x 26 in H 79 x 79 x 66 cm	COFFEE TABLE 32 in Dia x 16 in H 81 cm Dia x 41 cm H
MATERIALS Solid Teak Synthetic outdoor rope Molty foam Outdoor upholstery	ASSEMBLY Delivered fully assembled Fixed Teak legs and supports

01 Before first use

Remove packaging carefully and keep blades, staples and sharp tools away from the Teak, rope and upholstery. Inspect each seating piece and the coffee table for visible transit damage, unusual movement or misalignment before regular use. Contact ROCO before attempting a repair if anything appears incorrect after delivery.

02 Placement and everyday use

Place Meridian on a stable, level surface and lift each piece when repositioning it rather than dragging the fixed Teak supports. Use the sofas and chair for normal seated use only. Do not stand on the cushions, arms or coffee table, and keep hot, sharp or staining items away from the Teak tabletop unless suitable protection is used.

CARE & MAINTENANCE

Care for each material in the right way.

Meridian combines solid Teak, synthetic rope, Molty foam, outdoor upholstery and synthetic seat webbing. Routine care should be gentle, consistent and suited to each material rather than aggressive or chemical-heavy.

03 Solid Teak

Dust the Teak regularly and wipe light marks with a soft, slightly damp cloth. Dry the wood after cleaning and do not leave standing water on the frame or coffee table. Avoid abrasive pads, strong solvents, bleach and unsuitable household polish. Natural grain and tone variation are part of the material character.

04 Woven rope

Use a soft brush or dry cloth to clear dust from the woven rope and spaces between strands. For light marks, use a mildly damp cloth and allow the area to dry fully. Do not scrub aggressively, pull loose strands or use concentrated chemical cleaners.

05 Upholstery

Blot spills promptly with a clean, absorbent, colourfast cloth instead of rubbing them into the fabric. Avoid oversaturation, bleach and strong stain removers unless ROCO confirms that a cleaner is suitable for the selected upholstery. Keep removable covers fully dry before storage.

06 Cushions and protective covering

Plump and reposition loose Molty foam cushions periodically so they settle evenly, and store them in a dry, ventilated place during prolonged rain or extended non-use. A breathable furniture cover can reduce dust and exposure, but never trap wet cushions or moisture beneath it.

OUTDOOR USE & WARRANTY

Made for outdoor living. Maintained with care.

Outdoor furniture naturally experiences more exposure than indoor furniture. Sensible placement, dry cushion storage and timely maintenance will help Meridian retain its comfort and appearance.

07 Outdoor placement

Meridian may be used on patios, terraces, rooftops and garden seating areas, but this manual does not make unverified weatherproof, waterproof, UV-resistant or fade-proof claims. Avoid prolonged standing water and persistent dampness where practical, and move or cover the set when severe conditions are expected.

08 Structural care

If a sofa, chair or table develops unusual movement, cracking, loose rope, persistent noise or visible instability, stop using the affected piece and contact ROCO. Do not drill, dismantle, refinish, re-weave or arrange structural repair without ROCO guidance.

09 ROCO Confidence Warranty

The principal solid Teak frame and structural joinery receive 12 months of coverage for eligible manufacturing defects. Outdoor rope or weave, cushions and covers, applied finish and applicable outdoor hardware receive 6 months of component-specific coverage unless written order terms state otherwise. ROCO follows a repair-first approach. Normal outdoor ageing, expected Teak weathering, gradual cushion softening, fading, stains, moisture damage, unsuitable cleaning, misuse and unauthorised modification are not normally treated as manufacturing defects.

Customized orders: Specifications confirmed on your quotation, invoice or written order record take precedence over the standard information in this manual.

ROCO CUSTOMER CARE

Need assistance?

Contact ROCO early if the set does not look, feel or perform as expected. Clear photographs, order details and a short explanation help the after-sales team assess the concern more efficiently.

10 When to contact ROCO

Report visible transit damage, a missing or incorrect component, unusual structural movement, broken joinery, loose rope or another significant concern as soon as practical after delivery. Hidden manufacturing or workmanship concerns should be reported within the warranty period applicable to the affected component.

11 What to share

Please provide your order or invoice number, the product name, the relevant set configuration, clear photographs of the complete piece and affected area, and a short video when the concern involves movement, alignment, looseness or noise.

WHATSAPP	+92 317 6965610
EMAIL	info@roco.pk
AFTER-SALES	roco.pk/after-sales-request/
WARRANTY	roco.pk/warranty-policy/

Product identification: Meridian Outdoor Sofa Set | SKU MOSS-457.

Version 1.0 | September 2026 | Keep this manual with your order record.