

OWNER'S MANUAL

Stalwart Bookshelf Cabinet

Made for organised display and concealed storage. Regular care, balanced loading and secure placement will help preserve the Stalwart's finish, alignment and stability.

Product at a glance

OVERALL SIZE 35 in W x 22 in D x 81 in H 89 x 56 x 206 cm	LARGE SIZE 70 in W x 22 in D x 81 in H 178 x 56 x 206 cm
ASSEMBLY Delivered fully assembled	FINISHES Brown Wash / SeaDrift
STORAGE Adjustable open shelves Deep lower drawers	CONFIGURATION Single 35 in unit or paired 70 in arrangement

Before first use

- Remove packaging carefully. Keep blades, cutters and sharp tools away from finished surfaces.
- Place the cabinet on a dry, level indoor surface. Because the cabinet is 81 in high, secure it with a suitable anti-tip wall restraint before loading or regular use.
- Check that shelves are properly seated on their supports and that all drawers open, close and align smoothly.

Everyday use

- Distribute books and display pieces evenly across the shelves. Keep heavier items lower and avoid concentrated or excessive loads.
- Open one drawer at a time. Do not climb, sit or stand on shelves, drawers or the cabinet top.

CARE & MAINTENANCE

Simple care for lasting finish

The Stalwart combines solid Oak detailing, natural Oak veneer, furniture-grade plywood and selected engineered components. Use gentle, low-moisture care throughout.

Wood & veneer	Dust with a soft, dry microfiber cloth. For light marks, use a barely damp cloth and dry immediately. Always wipe with the grain where practical.
Spills	Wipe spills promptly with a clean, absorbent cloth. Do not allow water or other liquids to remain on shelves, drawer fronts, edges or joints.
Cleaning	Do not use bleach, acetone, thinner, abrasive cleaners, harsh polish or excessive water. For an uncertain treatment, contact ROCO before applying a product.
Shelves	Reposition shelves only when empty. Confirm each shelf support is fully seated before loading, and distribute weight evenly across the shelf.
Drawers & hardware	Keep drawer runners free of dust and debris. Do not overload drawers or force them if movement becomes uneven. Tighten loose knobs gently; do not lubricate runners without guidance from ROCO.
Finish & light	Keep the cabinet away from damp walls, strong heat and prolonged direct sunlight to reduce moisture damage and uneven fading.

PLACEMENT & SUPPORT

Use it well. We will stand behind it.

The Stalwart Bookshelf Cabinet is intended for indoor residential use in a dry, well-ventilated setting.

Important precautions

- Secure the cabinet to a suitable wall using an appropriate anti-tip restraint. Wall type determines the fixing method; use a qualified installer where needed.
- Do not allow children to climb, hang from or play on the shelves or drawers. Open only one drawer at a time.
- Keep the cabinet away from damp walls, water sources, heaters, open flames and prolonged direct sunlight.
- Do not drill, dismantle, alter the structure or arrange repair without written guidance from ROCO.
- If the cabinet becomes unstable, a shelf support loosens, or a drawer develops unusual movement or noise, stop using the affected area and contact ROCO.

Warranty guidance

Your cabinet is supported by the ROCO Confidence Warranty and any product-specific terms confirmed on your product page, quotation, invoice or written order confirmation. Coverage is component-specific. Qualifying plywood/MDF structural assemblies and standard hardware are normally covered for 12 months; indoor veneer, laminate and applied-finish adhesion are normally covered for 6 months. ROCO normally begins with assessment, adjustment, repair or replacement of the affected component.

Normal wear, natural wood or veneer variation, fading, moisture damage, overloading, accidental damage, misuse, harsh cleaning and damage linked to unauthorised repair or modification are not normally manufacturing defects. Report visible delivery concerns within 48 hours and do not return or repair the cabinet before receiving instructions from ROCO.

ROCO CUSTOMER CARE

Need assistance?

Contact us early if something does not look, feel or perform as expected. Clear information helps us assess the concern more quickly.

When to contact us

- Report visible transit damage, a wrong item or a major visible delivery concern within 48 hours of delivery.
- Stop using the affected area and contact ROCO if the cabinet becomes unstable, a shelf support loosens, or a drawer develops unusual movement or persistent noise.
- Report a hidden manufacturing, material or workmanship concern during the warranty period applicable to your order.

What to share

Please share your order or invoice number, the product name, selected size and finish, clear photographs of the complete cabinet and the affected area, and a short video if the concern involves movement, alignment or drawer operation.

WHATSAPP	+92 317 6965610
EMAIL	info@roco.pk
AFTER-SALES	roco.pk/after-sales-request/
WARRANTY	roco.pk/warranty-policy/

Version 1.0 | October 2026 | Keep this manual with your order record.