

OWNER'S MANUAL

Stalwart Grand Media Console

A large modular media system designed to bring display, concealed storage and cable organisation into one coordinated installation. Correct setup and dry indoor care help preserve its alignment, finish and stability.

Product at a glance

OVERALL SIZE 356 cm W x 56 cm D x 203 cm H 140 in W x 22 in D x 80 in H	CONFIGURATION 6-piece modular media console
SKU SGMC-453	ASSEMBLY Professional modular assembly and wall anchoring required
CONSTRUCTION Solid Oak detailing, furniture-grade plywood, natural Oak veneer and selected MDF	GLASS Tempered clear glass

Before installation

- Confirm the wall width and height, TV dimensions, socket positions, skirting and clear access before installation begins.
- Keep all modules, glass and hardware protected until the installer is ready to place them. Do not drag cabinet sections across the floor.
- Do not use the tall hutches until the lower modules are level, the system is aligned and both hutches are securely anchored to the wall.

Everyday use

- Keep doors and drawers closed when not in use. Do not stand, sit or climb on the console, drawers or shelves.
- Distribute stored items sensibly and avoid concentrated heavy loads. Do not force a drawer, hinge or shelf that is not moving normally.

INSTALLATION & ASSEMBLY

Set it up once. Set it up properly.

Stalwart is a modular furniture system, not a single fully assembled unit. Installation should be completed by trained furniture installers using the hardware supplied or approved for the order.

Professional installation sequence

- 01** Prepare the location. Clear the wall and floor area, confirm access to sockets and cable routes, and check that the floor is stable and reasonably level.
- 02** Position the lower modules. Place the base cabinets in their final order. Level and align the fronts before joining adjacent sections with the supplied or ROCO-approved fixings.
- 03** Install the bookcase hutches. Position each tall hutch over its intended outer base module. A hutch must not be left unsecured or treated as a freestanding upper cabinet.
- 04** Anchor to the wall. Secure both hutches with wall restraints suitable for the actual wall construction. The installer is responsible for selecting appropriate anchors for masonry, concrete, blockwork or other substrates.
- 05** Route cables before loading. Pass power, data and AV leads through the rear cable openings without trapping them behind hinges, drawer runners or cabinet joints.
- 06** Complete the final check. Confirm level, alignment, wall security, glass condition, shelf seating, door gaps and drawer movement before placing the TV equipment, books or decor.

Important installation rules

- Do not move the complete system as one assembled unit. Empty, disconnect and dismantle it into modules before relocation.
- Do not drill new holes, alter the cabinet backs, replace structural fixings or mount a TV bracket to the furniture without written ROCO approval.
- If a hutch, cabinet section or anchor becomes loose or unstable, remove nearby loads and contact ROCO before further use.

CARE & PLACEMENT

Protect the finish, glass and alignment.

Stalwart combines Oak detailing, natural Oak veneer, engineered cabinet construction, glass and metal hardware. Gentle cleaning and dry placement help preserve the finish and alignment.

Care & maintenance

Wood & veneer	Dust with a soft, dry microfiber cloth. For light marks, use a barely damp cloth and dry the surface immediately.
Spills & moisture	Blot promptly and do not allow water to remain on tops, panel edges, joints or the plinth. Keep the console away from damp walls and leaking services.
Glass doors	Use a clean soft cloth. Apply glass cleaner to the cloth rather than spraying directly onto the doors, timber frames or veneer edges.
Finish	Do not use bleach, acetone, thinner, abrasives, strong chemical polish or excessive water. Do not apply wax or oil unless ROCO confirms it is suitable for your finish.
Doors & drawers	Use moving parts gently and keep runners and hinges free from dust. If alignment changes or movement becomes stiff, do not force the component.
Media equipment	Keep cable openings clear and follow the ventilation requirements of your electronics. Do not block heat-producing equipment tightly inside closed cabinetry.

Placement & precautions

- Use indoors in a dry, well-ventilated room. Keep away from damp walls, strong heat, open flames and prolonged direct sunlight.
- Keep both hutches securely wall-anchored. Do not allow climbing on shelves, doors or drawers, and do not relocate the system while fully assembled.
- Natural Oak and veneer vary in grain and tone. Do not dismantle, refinish or arrange structural repair without ROCO guidance.

WARRANTY & CUSTOMER CARE

Support when you need it.

The Stalwart is supported by the ROCO Confidence Warranty and any product-specific written terms confirmed for your order.

Warranty guidance

MIXED STRUCTURAL ASSEMBLY	12 months
HINGES, SLIDES & STANDARD HARDWARE	12 months
INDOOR VENEER / FINISH	6 months
GLASS - VISIBLE DELIVERY ISSUES	Report within 48 hours
INSTALLATION / ALIGNMENT / MISSING FITTINGS	Report within 7 days

Written order terms apply if they differ. The 48-hour and 7-day periods are initial inspection windows, not the full warranty period for hidden manufacturing defects. Approved custom dimensions, finish choices and natural wood variation are not defects. Normal wear, scratches, moisture damage, misuse, unsuitable cleaning and unauthorised modification or repair are excluded.

When to contact us

- Report visible transit damage, a wrong component or glass damage within 48 hours; report installation, levelling, alignment or missing fittings within 7 days.
- Contact ROCO if a hutch, cabinet, shelf, door, drawer or wall restraint becomes unstable or stops operating correctly.
- Report hidden manufacturing, material or workmanship concerns during the applicable warranty period.

What to share

Share your order or invoice number, product name, clear photos of the complete console and affected area, and a short video if the concern involves movement, alignment, noise or hardware operation.

WHATSAPP +92 317 6965610	EMAIL info@roco.pk
AFTER-SALES roco.pk/after-sales-request/	WARRANTY roco.pk/warranty-policy/