

OWNER'S MANUAL | SKU ARW-461

Arcane Rattan Wardrobe

Designed for organised everyday storage. Regular care helps preserve the finish, natural cane and smooth operation.

Product at a glance

OVERALL SIZE 36 in W x 20 in D x 75 in H 91.4 x 50.8 x 190.5 cm	STORAGE 1 hanging rail, 1 shelf 2 internal drawers
WEIGHT Approximately 60 kg	ASSEMBLY Delivered fully assembled
CONSTRUCTION Kikar frame with furniture-grade plywood panels	DOOR PANELS Natural cane webbing

Before first use

- Remove packaging carefully. Keep blades and sharp tools away from the cane panels and finished surfaces.
- Check the delivery path, then place the wardrobe on a dry, level indoor surface. Move it empty with at least two adults, lifting from the lower frame or base.

Everyday use

- Distribute stored items sensibly, open one drawer at a time, and never climb, sit or place body weight on the doors, handles or drawers.

CARE & MAINTENANCE

Simple care for lasting character

Natural cane and finished wood benefit from dry, gentle care. When in doubt, contact ROCO before applying a cleaner or making an adjustment.

Wood frame & finish

Dust with a soft, dry cloth. For light marks, use a barely damp cloth and dry immediately. Avoid abrasive pads and strong chemical cleaners.

Natural cane

Use a soft brush or low-suction vacuum attachment. Do not soak, scrub or pull at the weave. Keep the cane dry.

Spills

Blot or wipe immediately with a clean, absorbent cloth. Keep excess moisture away from the cane and joints.

Doors & drawers

Keep hinges and drawer channels free from dust. Do not force a door or drawer, or lubricate hardware unless ROCO advises it.

Interior

Store dry belongings only. Avoid damp textiles or leaking containers, and allow the wardrobe to air naturally from time to time.

PLACEMENT & SUPPORT

Use it well. We will stand behind it.

The Arcane is intended for indoor residential use in a dry, well-ventilated setting.

Important precautions

- Keep the wardrobe away from damp walls, water sources, heaters, open flames and prolonged direct sunlight.
- Do not allow children to climb inside or play on the doors and drawers. For added safety, arrange suitable anti-tip anchoring for your wall type.
- Do not drill, dismantle, alter hardware or arrange structural repair without written guidance from ROCO.
- If the wardrobe becomes unstable or a door or drawer develops a persistent issue, stop using the affected part and contact ROCO. Move the wardrobe empty with at least two adults and lift from the base.

Warranty guidance

Covered under the ROCO Confidence Warranty: up to 24 months on qualifying solid-wood structure, 12 months on plywood structural assemblies and standard hardware, and 6 months on eligible indoor finish defects. ROCO follows a repair-first approach.

Normal wear, natural material variation, moisture damage, misuse, improper cleaning and unauthorised alterations are excluded. Report visible delivery concerns within 48 hours and contact ROCO before repair or return.

ROCO CUSTOMER CARE

Need assistance?

Contact us early if something does not look or perform as expected. Clear information helps us assess the concern quickly.

When to contact us

- Report visible transit damage, a wrong item or a major delivery concern within 48 hours.
- Contact ROCO if the wardrobe becomes unstable or develops a persistent door, drawer, hinge or structural issue.
- Report hidden manufacturing, material or workmanship concerns during the applicable warranty period.

What to share

Share your order or invoice number, the product name, clear photos of the complete wardrobe and affected area, plus a short video if the concern involves movement, alignment or noise.

WHATSAPP	+92 317 6965610
EMAIL	info@roco.pk
AFTER-SALES	roco.pk/after-sales-request/
WARRANTY	roco.pk/warranty-policy/

Version 1.0 | September 2026 | Keep this manual with your order record.