

OWNER'S MANUAL

Wharf Outdoor Dining Set

Made for relaxed six-person outdoor dining. Thoughtful care will help preserve the Wharf's solid-wood frame, rope weave, cushions and finish.

Product at a glance

DINING TABLE 78 in W x 39 in D x 29.5 in H 198 x 99 x 75 cm	DINING CHAIR 23.6 in W x 22.8 in D x 25.6 in H 60 x 58 x 65 cm
SEATING CAPACITY 6 persons 1 table + 6 dining chairs	SEAT HEIGHT 13 in (33 cm) Without cushion
CONSTRUCTION Solid Sheesham wood frame Synthetic outdoor rope	ASSEMBLY Delivered fully assembled SKU: WODS-467

Before first use

- Remove packaging carefully. Keep blades and sharp tools away from the cushions, rope weave and finished wood.
- Place the 6-seater set on a dry, level, stable surface. Confirm access for the fully assembled table and six chairs.
- After transit, allow the loose cushions to settle and shape them gently by hand before use.

Everyday use

- Use chairs only for seated use. Do not stand, climb or place concentrated weight on the arms, back or tabletop.
- Lift furniture when repositioning it; never drag. Use enough people to move the table safely.

CARE & MAINTENANCE

Simple care for lasting outdoor use

Wharf combines solid Sheesham, synthetic rope and loose cushions. Each material benefits from simple, regular care rather than aggressive cleaning.

Solid wood

Dust with a soft cloth. For light marks, use a barely damp cloth and dry immediately. Wipe away standing water promptly and avoid harsh chemicals or abrasive pads.

Rope weave

Remove dust with a soft brush or dry cloth. If needed, wipe gently with mild soapy water, then dry. Do not cut, pull, pressure-wash or scrub the rope.

Loose cushions

Plump and rotate the seat and back cushions regularly. Store them clean and dry during heavy rain or extended periods of non-use.

Upholstery & spills

Vacuum gently with a clean upholstery attachment. Blot spills immediately with a clean, colourfast cloth. Do not rub, scrub or saturate the fabric.

Cleaning & storage

Avoid bleach, acetone, thinner, abrasive cleaners and excessive water. For best longevity, keep the set covered or sheltered during prolonged harsh weather or when not in use for long periods.

PLACEMENT & SUPPORT

Use it well. Keep it looking its best.

Wharf is designed as a six-person outdoor dining set. Protect it from prolonged moisture, standing water and harsh exposure.

Important precautions

- Place the set on a stable, level surface and avoid areas where water routinely pools around the legs.
- Keep it away from open flames, high heat and strong chemical cleaners. Do not place hot cookware directly on the tabletop.
- Do not allow climbing on the table or chair backs. Keep sharp objects away from the rope and upholstery.
- Do not drill, dismantle or refinish without ROCO guidance. If a piece becomes unstable, develops damaged rope or persistent movement, stop using it and contact ROCO.

Warranty guidance

The Wharf Outdoor Dining Set is supported by the ROCO Confidence Warranty and any product- or order-specific written terms. Under the current outdoor-furniture schedule, structural frame and joinery are normally covered for 12 months; outdoor rope or weave, cushions and covers, applied finish and hardware are normally covered for 6 months, unless different written terms apply.

ROCO follows a repair-first, affected-component-first approach. Normal wear, cushion softening, fading, stains, moisture damage, misuse and unauthorised repair are not normally manufacturing defects. Report visible delivery concerns within 48 hours and do not arrange third-party repair or transport without ROCO instructions.

ROCO CUSTOMER CARE

Need assistance?

Contact us early if something does not look, feel or perform as expected. Clear information helps us assess the concern more quickly.

When to contact us

- Report visible transit damage, a wrong item or a major delivery concern within 48 hours.
- Report initial levelling, alignment or missing-fitting concerns within 7 days.
- Stop using an affected piece if it becomes unstable, develops damaged rope or persistent structural movement.
- Report hidden manufacturing, material or workmanship concerns during the applicable warranty period.

What to share

Please share your order or invoice number, the product name, clear photographs of the complete 6-seater set and the affected area, and a short video if the concern involves movement, instability or noise.

WHATSAPP	+92 317 6965610
EMAIL	info@roco.pk
AFTER-SALES	roco.pk/after-sales-request/
WARRANTY	roco.pk/warranty-policy/

Version 1.0 | September 2026 | Keep this manual with your order record.